



	X	Y	inches
A4	210 mm	297 mm	8.3 x 11.7
A3	297 mm	420 mm	11.7 x 16.5
A2	420 mm	594 mm	16.5 x 23.4
A1	594 mm	841 mm	23.4 x 33.1
50x70	500 mm	700 mm	19.7 x 27.6
70x100	700 mm	1000 mm	27.6 x 39.6


2 open poster bag




3 remove transport cardboard




4 insert your poster



5 close poster bag



6 insert poster bag into clip frame



POSTER BAG guide